

# OVERFAST®

## *Ultralight CarbonFiber Thru Axle*

**Thank you** for purchasing OVERFAST Ultralight Thru Axles! All thru axles are handmade and thoroughly tested before leaving the factory. Your safety is our top priority. We utilize non-painted lightweight water decals to reduce pollution and achieve a lighter weight. Please note that slight imperfections may be present, which are within acceptable standards.

### **Before you start**

OVERFAST Ultralight Thru Axles are available in several standards. Please ensure that the specifications of your purchase are compatible with your bicycle. If you cannot find a compatible thru axle for your bicycle specifications, please contact us for customization options.

### **Installation**

Before installation, please clean the slots of the frame or the fork carefully.

The thru axle must be used with our special washer. Make sure the washer is installed in the correct position. Do not use without a washer!

Lubricate the thread and the washer with lithium grease.

Install the wheel into the frame or fork and insert the axle.

Insert a good quality 6mm Hex key (not supplied) into axle. Ensure the head of the tool is inserted at least 15mm into the thru axle before tightening or untightening.

Turn the Hex key clockwise with a torque of 7.5-9 Nm. Periodically check the proper tightening of the axle.

### **Warning ▲**

Improper installation of the axle, including insufficient insertion of the hex key, excessive torque, misaligned threads, or lack of washers, can result in damage or detachment of the thru axle, leading to accidents. Please ensure to follow the installation instructions carefully.

Email: [overfastbike@gmail.com](mailto:overfastbike@gmail.com)

